

Зарядные устройства для аккумулятора TS, WH, BC, CH, M, HFR, HFGW, HFG, HF, HFW

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Казахстан +7(727)345-47-04

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Беларусь +(375)257-127-884

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Узбекистан +998(71)205-18-59

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия +996(312)96-26-47

эл.почта: skj@nt-rt.ru || сайт: <https://spark.nt-rt.ru/>

Battery Charger



Transformer Battery Charger

Suitable for 6V,12V,24V lead acid battery (AGM,GEL,STD etc),input voltage can be 120V/230V,100-240v wide voltage

Varies charging mode can be option:High Frequency, switch model,linear transformer,boost/engine start function charger

Varies charger style: Wheel charger,bench charger,heavy duty professional and DIY small maintainer chargers.

Varies special and popular function can be option: 13.6V power supply,back up function(memory last setting),alternator test,charging system test

Constant big charging current

Intelligent micro processor controlled unit&manual charging mode,fully automatic, from 4 to 9 stage charging stage

Fully protection: Short circuit,reverse polarity,over load, over heat protection

IP range from IP20 to IP65

Model	Picture	Charging Voltage(V)	Charging Amp(A)	Starting Amp(A)	Charging Mode	Certification
TS2260A		12/24	2/10/40 20	180	Automatic	GS
TS2250A		12/24	2/10/30	150	Automatic	GS
TS2230A		12/24	2/10/20	100	Automatic	GS
TS2200A		12/24	5/20/40 20	170	Munual	CE
TS2280A		12/24	20/30/50/70	200/180	Munual	CE
TS1200		6/12	40 5/20/40	200	Munual	UL

TS3540A		6/12	2/10/40	200	Automatic	ETL
TS3530A		6/12	2/10/30	150	Automatic	ETL
TS3520A		6/12	2/10/20	100	Automatic	ETL
TS3540M		6/12	40 2/10/40	200	Munual	ETL
TS3530M		6/12	30 2/10/30	150	Munual	ETL
TS3520M		6/12	20 2/10/20	100	Munual	ETL
WH400		12/24	15/25/45	135/125	Munual (Timer)	CE
WH500		12/24	15/25/45	135/125	Munual (Timer)	CE
WH600		12/24	15/25/45	135/125	Munual (Timer)	CE
WH900		12/24	20/30/50/70	200/180	Munual (Timer)	CE
WH1000		12/24	25/45/70/90	260/245	Munual (Timer)	CE
BC4M		12	4		Mannual	CE

BC6M		12	6		Manual	CE
BC6DVM		6/12	6		Manual	CE
BC8M		12	8		Manual	CE
BC12M		12	12		Manual	CE
BC4A		12	4		Automatic	CE
BC6A		12	6		Automatic	CE
BC6DVA		6/12	2/6		Automatic	CE
BC8A		12	2/8		Automatic	CE
BC12A		12	6/12		Automatic	CE
CH10DVA		6/12	10 2/10	/	Automatic	UL
CH10DVAS		6/12	10 2/10	55	Automatic	UL
CH15DVAS		6/12	15 2/15	10	Automatic	UL

CH30DVMS		6/12	6/30 2/30	150	Mannual	UL
CH40DVMS		6/12	40 10/40	200	Mannual	UL

Intelligent Battery Charger

Model	Picture	Charging Voltage(V)	Charging Amp(A)	Charging Mode	Display	Certification
M501		12	0.5	Intelligent automatic	LED	GS/BS/ SAA/ETL/CEC
M802		12	0.8	Intelligent automatic	LED	GS/BS/ SAA/ETL/CEC
M1001		12	1	Intelligent automatic	LED	GS/BS/ SAA/ETL/CEC
M1251		12	1.25	Intelligent automatic	LED	GS/BS/ SAA/ETL/CEC
HFP**DV		6/12	0.8/1/1.25/1.5/2	Intelligent automatic	LED	GS/ETL/ CEC
HFP**		12	0.8/1/1.25/1.5/2	Intelligent automatic	LED	GS/ETL/ CEC
HFGW**DV		6/12	0.8/1/1.25/1.5/2	Intelligent automatic	LED	GS
HFGW**		12	0.8/1/1.25/1.5/2	Intelligent automatic	LED	GS
<u>HFG1.5DV</u>		6/12	1.5	Intelligent automatic	LED	GS/SAA,ETL/CEC
HFG4DV		6/12	2/4	Intelligent automatic	LED	GS/SAA,ETL/CEC

HFG5DV		6/12	2.5/5	Intelligent automatic	LED	GS/SAA,ETL/CEC
HFG7DV		6/12	3.5/7	Intelligent automatic	Digital	GS/SAA,ETL/CEC
HFG8DV		6/12	4/8	Intelligent automatic	Digital	GS/SAA,ETL/CEC
HFG7DV-24		12/24	7/3.5	Intelligent automatic	Digital	GS/SAA,ETL/CEC
HFG8DV-24		12/24	8/4	Intelligent automatic	Digital	GS/SAA,ETL/CEC
HFG**		12	1,5/4/5/7/8	Intelligent automatic	Digital	GS/SAA,ETL/CEC
HF1.5		12	1.5	Intelligent automatic	LED	GS/SAA,ETL/CEC
HF1.5OB		12	1.5	Intelligent automatic	LED	GS/SAA,ETL/CEC
HF1.5DV		6/12	1.5	Intelligent automatic	LED	GS/SAA,ETL/CEC
HF2		12	2	Intelligent automatic	LED	GS/SAA,ETL/CEC
HF02DV		12	2	Intelligent automatic	LED	GS/SAA,ETL/CEC
HF04DV		6/12	2/4	Intelligent automatic	LED	GS/SAA,ETL/CEC

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Казахстан +7(727)345-47-04

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Беларусь +(375)257-127-884

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Узбекистан +998(71)205-18-59

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия +996(312)96-26-47

По вопросам продаж и поддержки обращайтесь:

эл.почта: skj@nt-rt.ru || сайт: <https://spark.nt-rt.ru/>